



ANNEXE / APPENDIX H

LISTE MATERIEL ELECTRONIQUE AUTORISE EN SERIE
AUTHORIZED ELECTRONIC EQUIPEMENT (PRODUCTION BOATS)

| | | | | | | | |
|--|--|--------------------------------------|---|---------------------|--|----------------------------|---|
| <p>AUTOHELM Everything</p> <p>B&G Triton² Digital display 20/20HV Display for H5000/Triton 10/10HV Display for H5000/Triton Triton² Autopilot controller H5000 graphic display. SKU 000-11542-001 H5000 race display. SKU 000.11543-001 WR10 Wireless Remote and BT1 Base Station</p> <p>FURUNO FI70 Instrument/Data Organizer FAP-7011C+FAP7002 (computer+display) FAP-7001</p> <p>GARMIN Reactor™ automatic remote control GHC™20 Autopilot Helm Control GMI™20 GNX20</p> <p>Nke Multidisplay TL25 SL50 Multigraphic PAD Display PAD Pilot Wired Display Remote Control Display radio controller Pilot Remote Control Crew Transmitter Gyropilot Transmitter Display Transmitter Universal Radio Receiver</p> <p>RAYMARINE E70328 p70s Colour Autopilot Control Head (Sail) E70329 p70Rs Colour Autopilot Control Head (Power) A80532 Follow-On Tiller steer (Standby – Power Steer – Standby) A80602 Autopilot Follow-On Tiller Steer Control Head (Auto-Power Steer-Auto) E15023 Sea talk SmartController Wireless Remote E15024 S100 Wireless SeaTalk autopilot Remote Control A18104 S100 only remote control A18105 Smart Controller A18106 Basis Station S100 E70063 i40 Speed Display System E70064 i40 Depth Display System E70065 i40 Wind E70066 i40 Bidata E70058 i50 Speed Wired Instrument Display E70059 i50 Depth Display E70060 i50 Tridata E70061 i60 Wind Display (Analog) E70062 Close Hauled Wind (Analog) E70327 i70s Multifunction Color Display</p> | <table border="1"> <tr> <td data-bbox="849 300 922 862"> <p>DISPLAYS / CONTROLLERS</p> </td> <td data-bbox="922 300 1541 862"> <p>T110-868 Wireless Mutli Digital Display T111-868 Multi Dual Digital Display T112-868 Wireless Multi Analogue Display T113-868 Wireless Multi Remote Display T061 Micro Compass with Strap Bracket (complete with T005) T060 Micro Compass T070-868 Micronet Race Master T074-868 Micronet Race Master System and Transducer T075-868 Micronet Race Master System, Triducer and Solar Panel T210 Wireless Maxi Display « Airflow function inside » T215 Wireless Dual Maxi Display</p> <p>SIMRAD IS42 Colour Instrument Display IS35 Digital Gauge IS42J Digital Gauge</p> </td> </tr> <tr> <td data-bbox="849 862 922 1832"> <p>WIND.</p> </td> <td data-bbox="922 862 1541 1832"> <p>AUTOHELM Everything</p> <p>B&G 213 Wind Sensor WS310 Wired Wind Sensor WS320 Wireless Wind Sensor</p> <p>FURUNO CV7 Windyplug FI-5001 FI-5001L</p> <p>GARMIN gWind™ Wireless 2 gWind™ transducer Wireless gWind™ transducer Wired gWind™ Transducer</p> <p>LCJ CV3F CV7 CV7-C CV7SF2 CV7-STBG CV7-V CV7-HR Sonic-Anemo-DZP</p> <p>Nke Masthead Unit HR Masthead Unit</p> <p>RAYMARINE T120 Wireless Wind System Z195 Wind Rotavecta (20m cable)</p> <p>Nb : use of any windvane extension is forbidden</p> </td> </tr> <tr> <td data-bbox="849 1832 922 2094"> <p>GPS ANTENNAS</p> </td> <td data-bbox="922 1832 1541 2094"> <p>AUTOHELM Everything</p> <p>B&G ZG100 GPS Antenna with Compass</p> <p>FURUNO GP330B ROGPS6</p> </td> </tr> </table> | <p>DISPLAYS / CONTROLLERS</p> | <p>T110-868 Wireless Mutli Digital Display T111-868 Multi Dual Digital Display T112-868 Wireless Multi Analogue Display T113-868 Wireless Multi Remote Display T061 Micro Compass with Strap Bracket (complete with T005) T060 Micro Compass T070-868 Micronet Race Master T074-868 Micronet Race Master System and Transducer T075-868 Micronet Race Master System, Triducer and Solar Panel T210 Wireless Maxi Display « Airflow function inside » T215 Wireless Dual Maxi Display</p> <p>SIMRAD IS42 Colour Instrument Display IS35 Digital Gauge IS42J Digital Gauge</p> | <p>WIND.</p> | <p>AUTOHELM Everything</p> <p>B&G 213 Wind Sensor WS310 Wired Wind Sensor WS320 Wireless Wind Sensor</p> <p>FURUNO CV7 Windyplug FI-5001 FI-5001L</p> <p>GARMIN gWind™ Wireless 2 gWind™ transducer Wireless gWind™ transducer Wired gWind™ Transducer</p> <p>LCJ CV3F CV7 CV7-C CV7SF2 CV7-STBG CV7-V CV7-HR Sonic-Anemo-DZP</p> <p>Nke Masthead Unit HR Masthead Unit</p> <p>RAYMARINE T120 Wireless Wind System Z195 Wind Rotavecta (20m cable)</p> <p>Nb : use of any windvane extension is forbidden</p> | <p>GPS ANTENNAS</p> | <p>AUTOHELM Everything</p> <p>B&G ZG100 GPS Antenna with Compass</p> <p>FURUNO GP330B ROGPS6</p> |
| <p>DISPLAYS / CONTROLLERS</p> | <p>T110-868 Wireless Mutli Digital Display T111-868 Multi Dual Digital Display T112-868 Wireless Multi Analogue Display T113-868 Wireless Multi Remote Display T061 Micro Compass with Strap Bracket (complete with T005) T060 Micro Compass T070-868 Micronet Race Master T074-868 Micronet Race Master System and Transducer T075-868 Micronet Race Master System, Triducer and Solar Panel T210 Wireless Maxi Display « Airflow function inside » T215 Wireless Dual Maxi Display</p> <p>SIMRAD IS42 Colour Instrument Display IS35 Digital Gauge IS42J Digital Gauge</p> | | | | | | |
| <p>WIND.</p> | <p>AUTOHELM Everything</p> <p>B&G 213 Wind Sensor WS310 Wired Wind Sensor WS320 Wireless Wind Sensor</p> <p>FURUNO CV7 Windyplug FI-5001 FI-5001L</p> <p>GARMIN gWind™ Wireless 2 gWind™ transducer Wireless gWind™ transducer Wired gWind™ Transducer</p> <p>LCJ CV3F CV7 CV7-C CV7SF2 CV7-STBG CV7-V CV7-HR Sonic-Anemo-DZP</p> <p>Nke Masthead Unit HR Masthead Unit</p> <p>RAYMARINE T120 Wireless Wind System Z195 Wind Rotavecta (20m cable)</p> <p>Nb : use of any windvane extension is forbidden</p> | | | | | | |
| <p>GPS ANTENNAS</p> | <p>AUTOHELM Everything</p> <p>B&G ZG100 GPS Antenna with Compass</p> <p>FURUNO GP330B ROGPS6</p> | | | | | | |

| | |
|---------------------|--|
| GPS ANTENNAS | <p>GARMIN GPS 19x HVS (NMEA 0183) GPS 19x NMEA 2000® GPS 24xd GPS GA™ 38 GPS/ GLONASS Antenna</p> <p>Nke External Passive GPS Antenna High Frequency GPS</p> <p>RAYMARINE T908 GPS Antenna with NMEA 0183</p> <p>SIMRAD GS25 GPS Antenna</p> |
| COMPUTERS | <p>B&G NAC-2 Autopilot Computer NAC-3 Autopilot Computer H5000 computer sealed with Hydra version H5000 pilot controller sealed with Hydra version. SKU 000-11544-001 H5000 pilot computer sealed with hydra version. SKU 000-11554-001</p> <p>FURUNO FAP-3012 FAP-7002</p> <p>GARMIN CCU (Course Computer Unit) Reactor 40 ECU (Electronic Control Unit)</p> <p>Nke Gyropilot 2 Computer Gyropilot 3 Computer</p> <p>RAYMARINE E70097 EV2 Evolution Sensor Core E70098 ACU-100 Acuator Control Unit E70099 ACU-200 Acuator Control Unit E70100 ACU400 Acuator Control Unit E70139 ACU-300 Acuator Control Unit E70430 ACU-150 Acuator Control Unit</p> |
| COMPASSES | <p>AUTOHELM Everything</p> <p>B&G Precision-9 Compass</p> <p>FURUNO PG500 PG700</p> <p>GARMIN 9-axis Heading Sensor SteadyCast™ Heasing Sensor Marine Heading Sensor</p> <p>LARS THRANE LT500 LT1000</p> <p>Nke Compas 9X Fluxgate Compass Regatta Compass Regatta Compass Bus Interface</p> <p>RAYMARINE E70096 EV-1 Sensor Core T909 Wireless Compass Transducer</p> |
| TRANSDUCERS | <p>AUTOHELM Everything</p> <p>B&G DST810 Depth/Speed/Temperature Sensor with Plastic Housing DST800 Depth, Speed, Temperature Sensor with Plastic Housing</p> |

| | |
|--------------------|--|
| TRANSDUCERS | <p>DT800 Depth and Temperature Sensor H5000/3000 Flush Plastic Speed Sensor</p> <p>FURUNO DST800</p> <p>GARMIN Airmar DST810 thru-hull smart transducer GTEMP10-TH thru-hull Temp Sensor Water Speed Sensor (4-pin)</p> <p>Nke Paddle Wheel Speed Sensor Depth Sounder</p> <p>RAYMARINE A22112 Plastic Smart transducer Th 12 deg Tilt DT800 A22165 Plastic Smart transducer Th 0 deg DT800 A22111 Transducer i70s A80373 P79S Smart In-Hull Transducer w/NLEA 2000 Connector T70278 P79S Smart Depth In-Hull Depth Transducer (DeviceNet Connector + STng adaptor) E26009 Thru-Hull depth plastic transducer (9m cable) M78713-PZ P19 LP TH Thru-Hull depth plastic (14m cable) E26030 Thru-Hull Depth Transducer Retractable (13,8m cable) E26027-PZ P66 Transom mount Depth Transducer (13m cable) E26001-PZ P79 internal adjustable Depth transducer E26010-PZ bronze TH Long Stem Depth Transducer (13,8m cable) E26006-PZ Transom Mount Depth/speed/temp (9m cable) A22154 DST800 analogue triducer E26028-PZ Transom mount Triducer (9m cable) A26043 Thru-Hull bronze Triducer (13,8 m cable) A26044 B744VL Long stem Bronze Thru-Hull Triducer (13,8 m cable) E26005 Speed Temperature Transom Mount Transducer (13,8 m cable) E26031 Thru-Hull speed/temperature plastic transducer (13,8 m cable) E25025 Plastic Thru-Hull speed/temperature sensor (20m cable) M78716 Bronze hru-Hull speed/temperature sensor (13,8m cable) T910 Triducer sensor (Speed, depth and Temperature) T911 Speed/temperature sensor T905 Depth transducer (50mm thru/in hull) T912 Thru-Hull Retractable Transducer</p> |
| TILLERS | <p>AUTOHELM Everything</p> <p>RAYMARINE A12004 ST1000 Plus A12005 ST2000 Plus</p> <p>SIMRAD Tillerpilot 22, SimNet/NMEA Tillerpilot 32, SimNet/NMEA Tillerpilot TP10</p> |

| | |
|----------------------|--|
| MISCELLANEOUS | <p>AUTOHELM Everyhting</p> <p>B&G RF25 Rotary Rudder Feedback Sensor RF300 Rotary Rudder Feedback Sensor H5000 Barometric Pressure Sensor</p> <p>FURUNO FI-5002 IF-NMEAFI</p> <p>GARMIN GNT™ 10 NMEA 2000® Transceiver GND 10</p> <p>nke Analog monitor Interface Log/Sounder Interface Dual Log & Sounder Interface HR100 Barometer Battery Monitor Loadcell monitor interface</p> |
|----------------------|--|

| | |
|----------------------|---|
| MISCELLANEOUS | <p>True wind option 12/13,6 V Converter Bus alimentation filter Rudder Angle Sensor 12V clutch option Input option NMEA input Interface Class B AIS Transpondeur</p> <p>RAYMARINE E70010 Multiple POD converter for iTC5 transducers E70361 Micronet to SeaTalkNG Gateway (Wireless Wind) M81105 Rudder transducer (10m cable) T121 Wireless Hull Transmitter T122 Wireless NMEA Interface T138 Solar Panel for Hull Transmitter</p> <p>LCJ Baroplug NMEA2000</p> |
|----------------------|---|

* Clauses d'antériorité :

- Speedo électromagnétique nke (airmar) pour les bateaux équipés avant le 1^{er} janvier 2022.

* Grandfather clause:

- *nke electromagnetic speed sensor (airmar) for equiped with before January, 1 2022.*